

## Apollo Gauge Calibration Settings

Tank Model	Set Switches ON	Height (mm)
650SL	1, 4, 5, 7, 8	1080
920SL	1, 4, 5, 7, 8	1070
1100SL	1, 3, 5	1305
1200LP	1, 5, 6	740
1300SL	1, 3, 6, 8	1260
1400HZ	1, 4, 5, 7, 8	1055
1450VT	1, 3	1175
2100HZ	1, 3	1160
2500HZ	1, 3, 5	1340
2500VT	1, 3, 6, 8	1270
3900VT	1, 3, 5	1300
5400VT	1, 3, 4, 5, 6, 7	1765
10000VT	1, 2, 3, 4, 5	2940
350ENV/BND	1, 4, 6, 7	950
650ENV/BND	1, 4, 5, 7, 8	1080
1000SSL	1, 3, 6, 8	1240
1000ENV/BND	1, 3	1160
1100ENV/BND	1, 3, 5	1305
1200BND/ENV	1, 5, 6	740
1300ENV/BND	1, 3, 6, 8	1260
1400ENV/BND	1, 4, 5, 7, 8	1055
1450ENV/BND	1, 3	1140
1650HZB	1, 3	1110
2000ENV/BND	1, 3	1160
2500ENV/BND	1, 3	1160
2700ENV/BND	1, 3, 5, 6, 8	1410
3500BND/ENV	1, 3, 4, 6	1570
5400ENV/BND	1, 3, 4, 5, 6, 7	1765
10000BND/ENV	1, 2, 3, 4, 5	2940
1300SLFS	1, 3	1220
1400FS	1, 3	1140
2500FS	1, 3, 6, 8	1170
2500SLFS	1, 3	1175
5000FS	1, 3, 4, 5, 6, 7	1765
10000FS	1, 2, 3, 4, 5	2940

NB: Battery for Apollo gauge is CR2430