

16 Inch Manhole Lid Replacement:



Parts

1 x 16" Lid

1x Vent

1x Paper backed Foam Seal

1x Hinge Pin



Instructions

- Attach Vent to underside of cap
- Knock Hinge Pin into Hinge hole
- Remove cover from Foam Seal Strip, cut to length and attach to underside of lid as shown



- Place lid into hole in tank and twist to open
- Attach lower half of lid to tank using 8 self-tapping screws or rivets in assigned positions