

Technical Data

DIAPHRAGM PUMP RANGE



Applies to the following models **only**:

- DP12/24.4 - DP12/220.17 - DP110.17 - DP12.17KIT

Please read carefully before commencing installation

Registered Office: HYTEK (GB) LIMITED, Delta House, Green Street, Elsenham, Bishop's Stortford CM22 6DS UK. Registered in England No. 1915382

Tel: +44 (0) 1279 815 600 Fax: +44 (0) 1279 812 978 email: info@hytekgb.com

Web: www.hytekgb.com

ENVIRONMENTAL INFORMATION



UK Regulation S1 2013 3113 requires that the equipment bearing this symbol on the product an/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product must be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities.

IMPORTANT WARNING NOTES

- 1. The pump MUST NOT be used to dispense petrol or other flammable liquids.
- 2. Installation of this equipment and its associated tank, pipe work and fittings should only be carried out by qualified installation engineers.
- 3. The installation must conform to all relevant electrical and local authority regulations and standards.

DESCRIPTION

The Hytek range of diaphragm pumps are self priming and suitable for pumping water or agricultural chemicals. All pumps are designed for intermittent duty and are fitted with pressure switches for on-demand operation.

INSTALLATION

The pumps are mounted via the soft rubber noise reducing mounts fitted to the base of each pump unit. The pumps are to be connected to a suitable power supply as follows:

12V DC: Red = (+) Positive 24V DC: Red = (+) Positive

Black = (-) Negative Black = (-) Negative

110V AC Brown = Live 230V AC: Brown = Live

Blue = Neutral Blue = Neutral

Yellow/Green = Earth Yellow/Green = Earth

OPERATION

- 1. Ensure the inlet and outlet fittings are securely connected.
- 2. Power up the pump and ensure that any nozzle or valve on the outlet is open. The pump will self prime and purge itself of any air present.
- 3. Close the nozzle/valve on the outlet and the pump will now stop.
- 4. Check the pump and all connections for any leaks after first use.

IMPORTANT: All Hytek diaphragm pumps are intermittent duty pumps, which have a duty cycle of a maximum of 30 minutes. This means after 30 minutes of constant usage the pump must be turned off and left to cool down for 30 minutes before it can be restarted. Electrical load and ambient temperature may affect the duty cycle. Using the pump beyond its recommended duty cycle may damage the pump unit, reduce the pumps lifespan, and could invalidate any warranty.

<u>SPECIFICATIONS</u>

See label on the pump unit for further information.

DECLARATION OF CONFORMITY

Company Name: Hytek (GB) Ltd

Address: **Delta House**

Green Street Elsenham

Bishop's Stortford Hertfordshire CM22 6DS

Date of Issue: 25th October 2022

Equipment Details: DP12/24.4, DP110.17, DP12/220.17,

DP12.17KIT Diaphragm Pumps

Applicable Directives: S1 2016 1091 Electromagnetic Compatibility Regulations

& Standards

S1 2016 1101 Electrical Equipment Safety Regulations

S1 2008 1597 Supply of Machinery Safety Regulations

S1 2016 1105 Pressure Equipment Safety Regulations

S1 2013 3113 Waste Electrical & Electronic Equipment Regulations

Declaration Number: UK079 Issue 3

Clive Wellings

On behalf of the above-named company, I declare under our sole responsibility that, on the date the equipment accompanied by this declaration is placed on the market, the equipment conforms with all technical and regulatory requirements of the above listed directives.

Clive Wellings, Process Co-ordinator

25th October 2022, Bishop's Stortford, Herts

THE INFORMATION CONTAINED IN THIS DOCUMENT IS PROTECTED BY COPYRIGHT © AND PROPERTY LAWS AND IS THE SOLE PROPERTY OF HYTEK (GB) LTD. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF HYTEK (GB) LTD IS PROHIBITED